

---

## Question: 1

A new administrator has just taken over an MX7000 Multi-Chassis Management Group and two-racks of PowerEdge servers. The previous administrator no longer works at the company and is not available. No one knows the password for the OME-M interface and the default password is not working.

What must be used to reset the password?

- A. iDRAC for one of the compute sleds.
- B. Left ear control panel.
- C. RACADM using a serial connection
- D. Management Module jumpers

**Answer: D**

## Question: 2

A server sled has a single mezzanine card installed in the correctly supported slot. To which IOM fabric(s) does the sled have access?

- A. Fabric A1 and Fabric A2
- B. Fabric A1 only
- C. Either Fabric A or Fabric B, depending on the configuration set in OME-M
- D. Fabric A1 and Fabric B1

**Answer: B**

## Question: 3

When performing "A1 the Box" management, what must be done to successfully connect to the Management Module?

- A. Configure PuTTY for a serial connection
- B. Change the baud rate to 128000
- C. Connect cables to the KVM
- D. Attach standard A-to-A USB cable to a laptop

**Answer: A**

## Question: 4

DRAG DROP

A technician is deploying a new MX7000 chassis using the Chassis Deployment Wizard.  
What is the correct order of steps followed by the wizard?

Configure iDRAC and IOM Quick Deploy Settings	STEP 1
Import Profile or join Multi-chassis Group	STEP 2
Configure Activity and Alerts	STEP 3
Define Groups	STEP 4
Update Firmware and configure Proxy	STEP 5

**Answer:**

Configure iDRAC and IOM Quick Deploy Settings	Import Profile or join Multi-chassis Group
Import Profile or join Multi-chassis Group	Configure Activity and Alerts
Configure Activity and Alerts	Configure iDRAC and IOM Quick Deploy Settings
Define Groups	Update Firmware and configure Proxy
Update Firmware and configure Proxy	Define Groups

**Question: 5**

What can be used as the firmware update source for OME-M within an MX chassis?

- A. Server Update UtilityBaseline from a Catalog
- B. Server Update UtilitySystem Live Image (SLI)
- C. Dell Update packageSystem Live Image (SLI)
- D. Dell Update PackageBaseline from a Catalog

**Answer: D**